




1. **Mount the Cameras:** Attach the cameras to the designated locations on your vehicle.
2. **Route the Video Cables:** Thread the **Extension Cables** through the vehicle and attach them to the cameras.
3. **Connect the Harness to the Brain:** Connect the **Harness** to the **360 Brain** and attach the **Extension Cables**.
4. **Power the System:** Connect the **Power Harness** to any 12-24V power source.
5. **Connect the Monitor:** Attach the monitor to 12V then connect it's **Video Cable** to the **Harness**.
6. **Turn On and Calibrate:** Turn on the vehicle and calibrate the system



Note: Triggers and the override button will be addressed in a separate page



Pro-Tip:
Mounting cameras asymmetrically or off-center (either vertically or horizontally) can help when awnings or lights obstruct the center position. The 360 brain handles the heavy lifting.